

URINAL FLANGE REPAIR KIT

No Need to Remove the Old Flange!



Wrap Metal Flange
Around Broken Flange



Close the Flange, Install the Bolts,
and You're Done!



#65784
With Neoprene Gasket



#68166
With Premium Gasket

Each Kit Contains: Adjustable Metal Flange, 2" S.S. Bolts (2), S.S. Nuts (2), S.S. Washers (2), and a Neoprene Gasket or Tight Seal Gasket